







































## Appendix 2, Assembly of adjustable slide rail

### Appendix 3, Support information

Before calling Cerlic support, please complete the information in this form and have it ready.

**Company\_\_ Name**


\_\_\_\_\_ **Phone**

\_\_\_\_\_ **E-mail** \_\_\_\_\_

**Sensor Type** \_\_\_\_\_

**Position / Tag**

\_\_\_\_\_




First go to the BB1/BB2 menu, it is accessed by pressing  and ENTER at the same time for five seconds. Select “System” and press ENTER.

**Version\_\_\_\_ Serial**

\_\_\_\_\_ **Box temp** \_\_\_\_\_

**Box heat**

\_\_\_\_\_

Leave the BB1/BB2 menu by pressing  and ENTER at the same time. Use  or  to select the sensor in the main display. Go to the sensor menu, it is accessed by pressing ENTER for five seconds. Select “System” and press ENTER.

**Type**

\_\_\_\_\_

**Serial**

\_\_\_\_\_

**SoftW**

\_\_\_\_\_

**Temp**

\_\_\_\_\_

Select “Info”, then press “ENTER” to go to the “info” menu.

**MS0**

\_\_\_\_\_

**MS1**

\_\_\_\_\_

**Cons 1**

\_\_\_\_\_

**Ch1**


\_\_\_\_\_

**Ch2**

\_\_\_\_\_

**Con**

\_\_\_\_\_

**Samp/s\_\_\_\_\_** Leave the BB2 menu by pressing  and ENTER at the same time.

## Appendix 4, Setup information

This sheet can be used to document the setup values of an O2X sensor.

**Sensor Type** \_\_\_\_\_

**Position / Tag** \_\_\_\_\_

In the System sub menu of the sensor menu the following information can be collected.

**Serial** \_\_\_\_\_

**SoftW** \_\_\_\_\_

In the Settings sub menu of the sensor menu the following parameters can be set.

**I-time** \_\_\_\_\_ **No**

**of decimals** \_\_\_\_ **Analog** \_\_\_\_\_

**Second** \_\_\_\_\_

In the Cleaning sub menu of the sensor menu the following parameters can be set. **Cleaner**

**Cleaning interval** \_\_\_\_\_

**Cleaning length** \_\_\_\_\_

**Cleaning freeze** \_\_\_\_\_

**Cleaning relay** \_\_\_\_\_

In the Scale / Alarm sub menu of the sensor menu the following parameters can be set. **Max**

\_\_\_\_\_ **Min**

**High-Alarm** \_\_\_\_\_ **Low-**

**Alarm** \_\_\_\_\_

**Alarm Relay** \_\_\_\_\_

Leave the BB2 menu by pressing  and ENTER at the same time.